

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://zarges.nt-rt.ru/> || zsc@nt-rt.ru

Mobile platform steps with ZARGES Ergo Stop



Details

Mobile access or work platforms that offer comfortable ascent. Ideal for work over long periods, even with tools and frequent changes of working position. Large-area platform with guardrail for safe and ergonomic working at heights.

- Different angles of inclination, 45° for comfortable access, 60° for confined spaces.
- Selection of tread widths 600 mm, 800 mm or 1000 mm.
- Serrated aluminium (R10) step and platform surfaces as standard. Also available as steel open grid (R12) and steel perforated plate (R13) for extra non-slip properties.
- Individually adjustable platform lengths.
- Platform steps instantly ready for use due to an innovative brake system.
- Chassis available in a non-static version as an option.
- ZARGES Ergo Stop - all four castors can be braked conveniently using the footpedal on the flight of steps.
- Individual guardrail configuration on the platform, optionally with swing door or pole barrier.
- Maximum flexibility with optional handrails and guardrails which can be removed without tools.
- Quick and simple assembly with the ZARGES connection system with a high level of pre-assembly.

Hints and special features

- We recommend equipping the product in accordance with the German Equipment and Product Safety Act (ProdSG) with two-sided handrails and, for steps with platforms or maintenance platforms, all-round fall protection (e.g. guardrails). If handrails or guardrails are not desired, the operator must ensure sufficient regulatory protection.
- Standard applied: DIN EN ISO 14 122.

More Information

Warranty 10 years

Variants

Order number	Chassis width	Inclination	Number of treads	Overall span	Tread width	Vertical height
40255014	1020 mm	45 °	5	1698 mm	600 mm	1070 mm
40255016	1620 mm	45 °	7	2128 mm	600 mm	1500 mm
40255018	1620 mm	45 °	9	2558 mm	600 mm	1930 mm
40255020	1220 mm	45 °	11	3017 mm	600 mm	2360 mm
40255022	1220 mm	45 °	12	3447 mm	600 mm	2790 mm
40255024	1220 mm	45 °	14	3877 mm	600 mm	3220 mm
40255026	1220 mm	45 °	16	4307 mm	600 mm	3650 mm
40255028	1420 mm	45 °	18	4737 mm	600 mm	4080 mm
40255030	1420 mm	45 °	20	5167 mm	600 mm	4510 mm
40255034	1020 mm	45 °	5	1698 mm	800 mm	1070 mm
40255036	1220 mm	45 °	7	2128 mm	800 mm	1500 mm

40255038	1220 mm	45 °	9	2558 mm	800 mm	1930 mm
40255040	1220 mm	45 °	11	3017 mm	800 mm	2360 mm
40255042	1220 mm	45 °	12	3447 mm	800 mm	2790 mm
40255044	1420 mm	45 °	14	3877 mm	800 mm	3220 mm
40255046	1420 mm	45 °	16	4307 mm	800 mm	3650 mm
40255048	1420 mm	45 °	18	4737 mm	800 mm	4080 mm
40255050	1620 mm	45 °	20	5167 mm	800 mm	4510 mm
40255054	1420 mm	45 °	5	1698 mm	1000 mm	1070 mm
40255056	1420 mm	45 °	7	2128 mm	1000 mm	1500 mm
40255058	1420 mm	45 °	9	2558 mm	1000 mm	1930 mm
40255060	1420 mm	45 °	11	3017 mm	1000 mm	2360 mm
40255062	1420 mm	45 °	12	3447 mm	1000 mm	2790 mm
40255064	1420 mm	45 °	14	3877 mm	1000 mm	3220 mm
40255066	1420 mm	45 °	16	4307 mm	1000 mm	3650 mm
40255068	1420 mm	45 °	18	4737 mm	1000 mm	4080 mm
40255070	1620 mm	45 °	20	5167 mm	1000 mm	4510 mm
40255074	1220 mm	60 °	5	1453 mm	600 mm	1250 mm

40255076	1420 mm	60 °	7	1707 mm	600 mm	1750 mm
40255078	1820 mm	60 °	9	1996 mm	600 mm	2250 mm
40255080	1620 mm	60 °	11	2285 mm	600 mm	2750 mm
40255082	1620 mm	60 °	13	2607 mm	600 mm	3250 mm
40255084	1620 mm	60 °	15	2896 mm	600 mm	3750 mm
40255086	1620 mm	60 °	17	3185 mm	600 mm	4250 mm
40255094	1220 mm	60 °	5	1453 mm	800 mm	1250 mm
40255096	1220 mm	60 °	7	1707 mm	800 mm	1750 mm
40255098	1620 mm	60 °	9	1996 mm	800 mm	2250 mm
40255100	1420 mm	60 °	11	2285 mm	800 mm	2750 mm
40255102	1420 mm	60 °	12	2607 mm	800 mm	3250 mm
40255104	1420 mm	60 °	15	2896 mm	800 mm	3750 mm
40255106	1620 mm	60 °	17	3185 mm	800 mm	4250 mm
40255114	1420 mm	60 °	5	1453 mm	1000 mm	1250 mm
40255116	1420 mm	60 °	7	1707 mm	1000 mm	1750 mm
40255118	1420 mm	60 °	9	1820 mm	1000 mm	2250 mm
40255120	1420 mm	60 °	11	2285 mm	1000 mm	2750 mm

40255122	1420 mm	60 °	13	2607 mm	1000 mm	3250 mm
40255124	1620 mm	60 °	14	3009 mm	1000 mm	3750 mm
40255126	1620 mm	60 °	17	3298 mm	1000 mm	4250 mm

- Алматы (7273)495-231

Ангарск (3955)60-70-56

Архангельск (8182)63-90-72

Астрахань (8512)99-46-04

Барнаул (3852)73-04-60

Белгород (4722)40-23-64

Благовещенск (4162)22-76-07

Брянск (4832)59-03-52

Владивосток (423)249-28-31

Владикавказ (8672)28-90-48

Владимир (4922)49-43-18

Волгоград (844)278-03-48

Вологда (8172)26-41-59

Воронеж (473)204-51-73

Екатеринбург (343)384-55-89

Иваново (4932)77-34-06

Ижевск (3412)26-03-58

Иркутск (395)279-98-46

Казань (843)206-01-48

Калининград (4012)72-03-81

Калуга (4842)92-23-67

Кемерово (3842)65-04-62

Киров (8332)68-02-04

Коломна (4966)23-41-49

Кострома (4942)77-07-48

Краснодар (861)203-40-90

Красноярск (391)204-63-61

Курск (4712)77-13-04

Курган (3522)50-90-47

Липецк (4742)52-20-81
- Магнитогорск (3519)55-03-13

Москва (495)268-04-70

Мурманск (8152)59-64-93

Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12

Новокузнецк (3843)20-46-81

Ноябрьск (3496)41-32-12

Новосибирск (383)227-86-73

Омск (3812)21-46-40

Орел (4862)44-53-42

Оренбург (3532)37-68-04

Пенза (8412)22-31-16

Петрозаводск (8142)55-98-37

Псков (8112)59-10-37

Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64

Самара (846)206-03-16

Санкт-Петербург (812)309-46-40

Саратов (845)249-38-78

Севастополь (8692)22-31-93

Саранск (8342)22-96-24

Симферополь (3652)67-13-56

Смоленск (4812)29-41-54

Сочи (862)225-72-31

Ставрополь (8652)20-65-13

Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17

Тамбов (4752)50-40-97

Тверь (4822)63-31-35
- Тольятти (8482)63-91-07

Томск (3822)98-41-53

Тула (4872)33-79-87

Тюмень (3452)66-21-18

Ульяновск (8422)24-23-59

Улан-Удэ (3012)59-97-51

Уфа (347)229-48-12

Хабаровск (4212)92-98-04

Чебоксары (8352)28-53-07

Челябинск (351)202-03-61

Череповец (8202)49-02-64

Чита (3022)38-34-83

Якутск (4112)23-90-97

Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://zarges.nt-rt.ru/> || zsc@nt-rt.ru